



**Instructions for Europa Unit  
BP 9758**

[info@lovencare.com.au](mailto:info@lovencare.com.au)  
[www.lovencare.com.au](http://www.lovencare.com.au)



Congratulations on your new quality Love N Care product from our exclusive range of baby products. This exceptional design combines the most unique features that any baby product offers.

We are confident that you will appreciate its many highlights, including its reliability and durability. Your new product has been manufactured to comply with the Highest Quality Standards and comes with a 12-month warranty.

As you will soon learn there are many more great features about your new Love N Care product.

Maximum weight capacity of should not exceed **22KG**  
Complies with: **AS 2088:2000**

Safety guidelines and instructions must always be followed before making use of this product, please retain these instructions for future reference:

### WARNING:

- Always make sure the unit is completely opened and locked before using.
- Never leave your child unattended in the unit
- Do not use the unit on stairways or escalators.
- This unit is not a toy, do not allow children to climb into the unit unassisted as this may cause the unit to tip over and cause injury to your child.
- To avoid serious injury always use the harness provided to secure your child.
- Periodically check the restraint system to make sure it is secured.
- Care should be taken while folding and unfolding unit to prevent finger entrapment.
- Ensure your child's fingers, hands and all other body parts are clear from any moving part when adjusting the seat or handle on your unit.
- Basket maximum weight should not exceed 5kg.
- Discontinue use of the unit should it become damaged.
- Missing parts and damaged parts should be replaced immediately to prevent any injuries.
- Brakes must be used when you stop the pram.
- With Toddler Seat attached this unit can take children up to 4 years old or 25Kg in the unit seat position and 15kg in the lower seat position.

### CARE AND MAINTENANCE:

To ensure your unit lasts a long time you must maintain it. To maintain the unit follow the below steps:

- Plastic and metal parts may be sponged clean with warm water and a mild detergent.
- Do not clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Storing a damp baby stroller will encourage mildew to form, so make sure to thoroughly dry all parts before storing.
- After exposure to damp conditions, dry off with a soft cloth and allow to completely dry.

### PARTS LIST:

Below is a list of items which you should find included with your new pram:

- a) 1 Unit
- b) 2 Rear wheels
- c) 1 Front wheel
- d) 2 Rear wheel axles
- e) 2 Rear guards
- f) 1 Canopy



a



b



c



d



e



f

### Rear Guards:

This unit has been equipped with 2 rear guards for the rear wheels. Please ensure to attach these before fitting the wheels.

- Lay the unit flat and slot guards into guides on side of frame **(As shown in Fig 1)**
- **(As shown in Fig 2.)**
- Repeat the same process for second wheel.

Fig 1



Fig 2



### Inserting the wheels:

#### Rear Wheels

- Install one wheel at a time by inserting the wheel into the housing unit on the frame until you hear an audible click. Pull on wheel to ensure it is attached correctly. **(As shown in Fig 3)**
- Repeat process for second wheel

#### Front wheel:

- Completely extend the swivel lock and insert wheel rod into unit frame, **(As shown in Fig 4)**
- Release the swivel lock and check the wheel is correctly fitted before use.

Fig 3



Fig 4



### Using the Brakes:

**Always apply brakes when parking your unit. Apply brakes before loading/unloading your children.**

- To apply the brakes, simply push the lever down, to release brakes simply lift lever up. **(As shown in Fig 5)**



### Fixing/Swiveling wheels:

- Front wheel can be fixed, to do this simply pull the plastic lever across located above the front wheel
- To swivel simply reverse this action **(As shown in Fig 6)**



### Opening the Jogger:

- Lift unit, keeping fingers clear of any hinges, extend the front of the unit and set all wheels on the ground. **(As shown in Fig 7)**
- Lift the handle until it locks into place with an audible click. Ensure it is opened properly before commencing. **(As shown in Fig 8)**



Fig 7



Fig 8



To adjust the Backrest:

- To recline the back rest simply hold and squeeze the red sides together and pull up or down to your desired position. **(As shown in Fig 9)** **NOTE: It will be easier and safer to recline the backrest before you place your child in the unit.**



To adjust the harness:

This jogger has been designed with a 5 – point harness for the safety of your child, your child must always be secured in this harness whilst in use. **(As shown in Fig 10)**

- The safety harness is adjustable, and to release the harness you should press the buckle at either side to remove it.
- To secure the harness push the buckles in, you will hear a click which means the harness has been secured.
- To adjust the harness simply thread and tighten accordingly to suit your child.



Adjusting the Handle:

- Depress both side buttons and move handle either up or down.
- Release buttons once you have reached your desired position to lock handle in place. **(As shown in Fig 11)**



Attaching the Hood:

- To attach the hood simply push each side into the side frame of unit. **(As shown in Fig 12)**
- Then using the Velcro straps included secure the sides and back part of the hood to the frame of the unit.
- To adjust the hood, simply push forward or back from the front of the hood.
- The hood also has a window to enable you to see your baby at all times, and also a mosquito net which is zipped to the front of the hood to cover your baby while you're out and about. **(As shown in Fig 13)**

Fig 12



Fig 13



To Close the Stroller:

- To close your unit simply hold both side levers and pull up to release the mechanism then fold down the unit down until completely closed. Ensure the locking clip is secured before trying to pick unit up. **(As shown in Fig 14)**



### ATTACHING THE TODDLER SEAT:

**This toddler seat is sold separately.**

The toddler seat can be fitted to either the front or back of the unit.

To attach to front of unit:

- Place the backrest of the unit into the newborn position and apply the brakes.
- Remove the front bar from the unit.
- Insert the correct sides of the seat into the side tubes ensuring the seat is fully engaged and clicks into place. **(As shown in Fig1)**
- Your toddler Seat is now ready for use.



To attach Behind the Unit:

- Place the unit into the toddler position
- Align seat with the tubes on the back of the unit
- Insert the toddler seat into the tubes until they are fully engaged. **(As shown in Fig 2)**
- The toddler seat is now ready for use.
- **NOTE:** Always load heavier child into the front seat first, then place lighter child in the back. Always unload rear toddler first.



**A CHILDS SAFETY IS YOUR RESPONSIBILITY**

Never leave a child unattended.

Children should be harnessed at all times.

Use seat belt provided to avoid serious injury from falling or sliding.

The child should be kept clear of moving parts when making any adjustments.

For safety this unit requires inspection and maintenance by the user.

Overloading, incorrect folding and the use of non-approved accessories may damage or break this unit.

Be certain the unit is fully and properly latched into position before allowing child near stroller.

Always read instructions carefully.

Single Maximum weight should not exceed 25kg Double max weight 40kg

Double maximum weight 25kg in front fitting position, 15kg in rear position.

This unit should not be used near exposed flame.

Always apply brakes when unit is parked or loading or unloading children.

This unit is not suitable for Running, Jogging or Skating.

This product is produced in accordance with Safety Standards

EN1888

AS/NZ 2088:2000

**lovehcare**



Another reliable product from Love N Care  
Excellence ♥ Intelligence ♥ Caring

**Contact Us:**

1300 732 599