

loveⁿcare™



3 SIXTY

INSTRUCTION MANUAL

PLEASE RETAIN FOR FUTURE REFERENCE **BP 5770**

loveⁿcare™

Congratulations on your new quality Love N Care product from our exclusive range of baby products. This exceptional design combines the most unique features that any baby product offers.

We are confident that you will appreciate its many highlights, including its reliability and durability. Your new product has been manufactured to comply with the Highest Quality Standards and comes with a 12-month warranty.

As you will soon learn there are many more great features about your new Love N Care product.





WARNING

DO NOT USE A HIGHCHAIR UNTIL YOUR CHILD CAN SIT UP UNAIDED

DO NOT LEAVE CHILDREN UNATTENDED

THE HARNESS MUST ALWAYS BE USED AND CORRECTLY FITTED TO AVOID INJURIES CAUSED BY FALLS

POSITION THE HIGHCHAIR AWAY FROM SOLID STRUCTURES TO AVOID INJURIES CAUSED BY FALLS OR ACCESS TO OTHER DANGEROUS ITEMS.

IF UNRESTRAINED AND UNSUPERVISED, CHILDREN MAY STAND UPON THE CHAIR AND AS A RESULT TOPPLE OVER OR SLIDE UNDER THE TRAY, FALLING TO THE GROUND.

A CHAIR MAY TIP OVER AS A RESULT OF CHILDREN ROCKING BACK AND FORTH WHILE STANDING ON THEM.

ALWAYS PLACE THE CHAIR AWAY FROM WINDOWS, UNSECURED DOORWAYS, STOVES, APPLIANCE CORDS, AND CURTAINS OR BLINDS CORDS. MAKE SURE YOUR CHILD CANNOT PUSH AGAINST A VERTICAL SURFACE SUCH AS A WALL OR CUPBOARD, THEREBY TIPPING OVER THE CHAIR.

BEFORE PLACING YOUR CHILD IN THE HIGHCHAIR ENSURE THAT THE NOZZLE ON THE SEAT SUPPORT IS TIGHTENED AND THE SEAT IS STABLE AND SECURE.

ALWAYS ENSURE THAT THE HIGHCHAIR HAS BEEN FULLY ASSEMBLED CORRECTLY BY FOLLOWING THE INSTRUCTION SHEET PROVIDED.

FAILURE TO DO SO CAN CAUSE HARM TO YOUR CHILD.

USE THE HIGHCHAIR ONLY ON A STABLE SURFACE.

IF THE HIGHCHAIR IS DAMAGED PLEASE DISCONTINUE USE AND CONTACT LOVE N CARE ON THE NUMBERS PROVIDED IN THIS INSTRUCTION MANUAL.

DO NOT PLACE ANY CHILDREN, ANIMALS OR OTHER OBJECTS TO BE PLACED UNDER OR NEAR THE CHAIR WHILST THE CHILD IS SEATED IN THE CHAIR.

DO NOT FORCE THE TRAY INTO CHILD WHEN ADJUSTING THE TRAY, ALWAYS ALLOW BREATHING SPACE FOR THE CHILD.

DO NOT MOVE THE HIGHCHAIR WHILST THE CHILD IS SEATED.

MAXIMUM WEIGHT CAPACITY OF HIGH CHAIR SHOULD NOT EXCEED 25KG

PARTS LIST



WHAT YOU SHOULD HAVE IN THE BOX


- #1 - SEAT SUPPORT
- #2 - 5 POINT HARNESS
- #3 - SEAT
- #4 - GAS LIFT
- #5 - BASE CONNECTOR WHEELS
- #6 - BASE
- #7 - LINER PAD
- #8 - HIGH CHAIR LINER
- #9 - HIGH CHAIR LOWER TRAY
- #10 - TOP TRAY
- #11 - CROTCH SUPPORT

HOW TO ASSEMBLE


FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY.

STEP 1. REMOVE ALL PARTS FROM THE PACKAGING

STEP 2. CONNECT THE BASE CONNECTOR WHEELS #5 TO THE BASE #6 THEY SHOULD SLIDE IN.
INSERT THE GAS LIFT INTO THE BASE MAKE SURE YOU HEAR IT CLICK



STEP 3. ATTACH THE SEAT SUPPORT #1 TO THE GAS LIFT #4
TURN THE NOZZLE SCREW TO ATTACH THE SUPPORT.
PLEASE ENSURE IT IS TIGHTENED.



STEP 4.

**ASSEMBLE THE SEAT #3 TO THE SEAT SUPPORT #1
ENSURE THAT THE SIDES SNAP IN AND YOU HEAR THE BUTTONS CLICK**



STEP 5.

**ATTACHING THE 5 POINT HARNESS #2 TO THE SEAT #3
SLIDE IN THE MEDAL ENDS OF THE 5 POINT HARNESS IN THE SLOTS ON THE SEAT
DEPENDING ON THE HEIGHT REQUIRED**



STEP 6.

ATTACH THE LINER #8 TO THE SEAT 3#

**AFTER THE LINER IS ON THE SEAT YOU CAN THREAD THROUGH THE 5 POINT HARNESS #2
THERE IS AN ADDITION LINER PAD #7 FOR ADDED SUPPORT.**

THE HARNESS #2 SHOULD BE THREADED THROUGH BOTH THE LINER #8 AND THE PAD #7



STEP 7.

ATTACH THE CROTCH SUPPORT #11 TO THE LOWER TRAY #9



STEP 8.

**SLIDE THE LOWER TRAY #9 ONTO THE SEAT #3 ARMS
THE TOP TRAY #10 CAN SIT ON TOP OF THE LOWER TRAY.**




HOW TO USE

ADJUST THE HEIGHT OF THE SEAT:

TO ADJUST THE HEIGHT OF THE SEAT #3 ENSURE THAT THE CLAMPING RING IS UNLOCKED
PUSH DOWN ON BOTH SIDES OF THE TRAY TO DECREASE THE HEIGHT OF THE HIGHCHAIR.
IF YOU WANT TO RAISE THE HIGHCHAIR STEP ON THE PEDAL AND IT WILL RAISE UP.
ONCE YOU HAVE YOUR DESIRED HEIGHT LOCK THE CLAMPING RING.



WARNING:
DO NOT STEP ON THE CLAMPING
RING WHEN IT IS LOCKED




HOW TO RECLINE THE BACKREST:

YOU CAN ADJUST THE BACKREST OF THE SEAT #3 TO THREE DIFFERENT POSITIONS.

YOU NEED TO PUSH UP ON THE REAR LEVER AND EITHER PUSH THE SEAT UP OR DOWN TO THE POSITION REQUIRED. THEN YOU MUST RELEASE THE LEVER.

THE BACK REST CAN BE ADJUSTED WHILST THE CHILD IS SEATED.




TO INSTALL AND OPERATE THE TRAY:

TO INSTALL THE LOWER TRAY #9 GRAB BOTH SIDES OF THE TRAY AND PULL THE ADJUSTMENT LEVERS OUT. THEN SLIDE ON TO THE ARMS OF THE SEAT . THE SEAT TRAY CAN BE ADJUSTED TO DIFFERENT POSITIONS BY RELEASING THE MECHANISM TO THE POSITION NEEDED.



HOW TO USE 5-POINT HARNESS:

CAREFULLY PLACE THE CHILD IN THE SEAT #3 AND BRING THE SAFETY HARNESS AROUND THE CHILDS WAIST AND OVER THE SHOULDERS. PLACE THE CROTCH STRAP BETWEEN THE CHILDS LEGS. INSERT HOOK OF EACH SHOULDER STRAP INTO THE HOLE ON THE TOP OF THE WAIST STRAP BUCKLE. ONCE THE TWO ARE CONNECTED PLACE THE MALE WAIST BUCKLE INTO THE FEMALE CROTCH STRAP END. REPEAT ON BOTH SIDES. TIGHTEN THE HARNESS TO BE SNUG AROUND THE CHILDS WAIST AND OVER THE CHILDS SHOULDERS. TO RELEASE: SQUEEZE THE SIDES OF THE BUCKLES (LOCATED IN THE CENTRE). YOUR CHILD SHOULD BE SECURELY HARNESSSED AT ALL TIMES AND SHOULD NEVER BE LEFT UNATTENDED.



HOW TO MOVE THE HIGH CHAIR:

TILT THE HIGHCHAIR ON ITS SIDE AND USE THE BASE CONNECTOR WHEELS #5 TO TRANSPORT THE HIGHCHAIR.

WARNING:
DO NOT MOVE THE HIGHCHIR
WHILST THE CHILD IS SEATED



CLEANING AND MAINTENANCE

ALL LOVE N CARE PRODUCTS HAVE ONE YEAR WARRANTY FROM THE DATE OF PURCHASE.

IT IS RECOMMENDED TO REGULARLY INSPECT AND MAINTAIN MOVEMENT OF LOCKING DEVICES AND SECURITY OF ESSENTIAL COMPONENTS.

REGULARLY CHECK ALL PARTS FOR WEAR AND TEAR.

DO NOT USE SPRAY LUBRICANTS, SIMPLY WIPE CLEAN AFTER USE.

THE SEAT LINER CAN BE CLEANED BY SPONGING WITH WARM SOAPY WATER AND A MILD DETERGENT. A MILD DISINFECTANT MAY BE USED IF DESIRED.

STUBBORN MARKS MAY BE REMOVED WITH A NON ABRASIVE CREAM CLEANER.


NEVER CLEAN WITH ABRASIVE, AMMONIA BASED, BLEACH BASED OR SPIRIT TYPE CLEANERS.

THE TOP TRAY#10 IS DISHWASHER SAFE

THE LOWER TRAY #9 CAN BE CLEANED WITH A DAMP CLOTH.

FABRIC CARE

- HAND WASH ONLY
- DO NOT BLEACH
- DO NOT TUMBLE DRY
- DO NOT IRON
- DO NOT WRING
- DO NOT DRY CLEAN





Contact Us

Head Office:

Love N Care Pty Ltd.
297-299 Canterbury Rd, Revesby
NSW 2212 Australia
Contact No: 02 9774 4655
Fax: 02 9774 4633
Email: info@lovencare.com.au
Website: www.lovencare.com.au

Western Australia

5 Modal Crescent
Canning Vale WA 6155 Australia
Contact No: 08 9455 4972
Fax: 08 9455 4728

Brisbane

7-9 Eileen Street
Underwood QLD 4119 Australia
Contact No: 07 3290 4217
Fax: 07 3209 5019

Ireland

DMG House
Deansgrange Industrial Estate
Deansgrange Co. Dublin
Phone: +3531 2190254
Fax: +3531 2802734
Website: www.lovencare.ie