




VOYAGER




Instruction Manual

PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE



Congratulations on Purchasing
your new Love N Care Stroller

Within no time you should be able
to have this stroller ready to
meet your beautiful child :)



VOYAGER



SAFETY GUIDELINES AND INSTRUCTIONS MUST ALWAYS BE FOLLOWED BEFORE MAKING USE OF THIS PRODUCT. PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE OF THIS STROLLER.

THIS PRODUCT COMPLIES WITH PRODUCT SAFETY STANDARD AS/NZS 2088:2009



WARNINGS

TO AVOID INJURY OR DEATH

FOLLOW THE MANUFACTURER'S INSTRUCTIONS.

PUT ON ALL THE BRAKES WHENEVER YOU PARK THE STROLLER.

ALWAYS APPLY THE BRAKES WHENEVER THE STROLLER IS STATIONARY.

DO NOT LEAVE CHILDREN UNATTENDED.

SECURE THE CHILD IN THE HARNESS AT ALL TIMES.

DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS STROLLER.

DO NOT USE THIS SEAT WITH ANY OTHER MODELS OF STROLLER.

MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE STROLLER, OTHERWISE THEY MAY BE INJURED.

CHECK THAT ALL SAFETY LOCKS ARE ENGAGED BEFORE PLACING A CHILD IN THE STROLLER.

USE THE HARNESS AT ALL TIMES.

WHEN NOT IN USE DISCONNECT SHOULDER STRAPS FROM THE WAIST STRAP AND/OR BUCKLE TO PREVENT STRANGULATION.

THE HARNESS CAN FORM LOOPS WHICH MAY BE A STRANGULATION HAZARD.

NEVER LEAVE A HARNESS CONNECTED WHEN NOT FITTED TO A CHILD IN THE STROLLER.

TO AVOID SERIOUS INJURY ALWAYS USE THE HARNESS PROVIDED TO SECURE THE CHILD. (ADJUST THE STRAPS TO SUIT THE SIZE OF YOUR CHILD'S BODY)

IT IS UNSAFE TO USE ACCESSORIES OTHER THAN THOSE SUPPLIED BY LOVE N CARE.

CARE SHOULD BE TAKEN IF THE STROLLER IS TO BE USED ON STAIRS OR ESCALATORS.

THIS STROLLER SHOULD NOT BE USED NEAR AN OPEN FIRE OR AN EXPOSED FLAME.

CARE SHOULD BE TAKEN WHILST FOLDING AND UNFOLDING THE STROLLER TO PREVENT FINGERS BEING TRAPPED.

ENSURE YOUR CHILD'S FINGERS, HANDS AND ALL OTHER BODY PARTS ARE CLEAR FROM ANY MOVING PARTS WHEN ADJUSTING THE SEAT OR HANDLE ON YOUR STROLLER.

THE BASKET CAN NOT BE REMOVED.

USE THE TETHER STRAP TO PREVENT THE STROLLER FROM ROLLING AWAY.

DO NOT RUN WHILE USING THIS STROLLER.

THE UPRIGHT POSITIONS ARE NOT SUITABLE FOR USE WHEN CHILD IS LESS THAN 6 MONTHS OLD. THE LOWEST RECLINE POSITION SHOULD BE USED FOR NEWBORNS.

MAXIMUM WEIGHT OF CHILD SHOULD NOT EXCEED: 17KG

MAXIMUM WEIGHT FOR BASKET: 4KGS

MAXIMUM WEIGHT FOR CANOPY POCKET: 1KG

*PICTURES USED IN THIS MANUAL ARE FOR ILLUSTRATIVE PURPOSES ONLY. THE ACTUAL STROLLER MAY VARY IN DISPLAY.



CARE AND MAINTENANCE

All Love N Care products have one year warranty from the date of purchase.

It is recommended to regularly inspect and maintain movement of locking devices and security of essential components.

To prolong the life of your stroller keep it clean and do not leave it in direct sunlight or in the boot of your car for extended periods of time.

Regularly check all parts for wear and tear. Lubricate if tight.

Removable fabric covers and trims may be cleaned using warm water with a household soap or mild detergent. Allow it to dry completely before re-use.

Non-removable fabrics and trims may be spot cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing away.

Never clean with abrasive, ammonia based bleach based or spirit type cleaners.

If the wheels become damaged or worn discontinue use and replace.

FABRIC CARE

- HAND WASH ONLY
- DO NOT BLEACH
- DO NOT TUMBLE DRY
- DO NOT IRON
- DO NOT WRING
- DO NOT DRY CLEAN





WARRANTY AGAINST DEFECTS

ALL LOVE N CARE PRODUCTS ARE GUARANTEED FOR TWELVE MONTHS FROM THE DATE OF PURCHASE.

OUR GOODS COME WITH GUARANTEES THAT CANNOT BE EXCLUDED UNDER THE AUSTRALIAN CONSUMER LAW. YOU ARE ENTITLED TO A REPLACEMENT OR REFUND FOR A MAJOR FAILURE AND FOR COMPENSATION FOR ANY OTHER REASONABLY FORSEEABLE LOSS OR DAMAGE. YOU ARE ALSO ENTITLED TO HAVE THE GOODS REPAIRED OR REPLACED IF THE GOODS FAIL TO BE OF ACCEPTABLE QUALITY AND THE FAILURE DOES NOT AMOUNT TO A MAJOR FAILURE.

THIS COVERS AGAINST FAULTS WHICH DEVELOP THROUGH FAULTY MATERIALS AND WORKMANSHIP. MISUSE, ACCIDENTAL DAMAGES, NORMAL WEAR AND TEAR OR NEGLECT ARE NOT COVERED.

IF A FAULT BECOMES APPARENT, PLEASE RETURN THE ITEM TO THE STORE OF PURCHASE WITH YOUR RECEIPT. YOU MUST INFORM THE STORE WHAT THE DEFECT IS. WE WILL THEN ARRANGE FOR ITS REPAIR OR IT WILL BE ASSESSED FOR REPLACEMENT AS EXPEDIENTLY AS POSSIBLE. THE BENEFITS OF THIS WARRANTY ARE IN ADDITION TO OTHER RIGHTS AND REMEDIES UNDER THE LAW IN RELATION TO THE GOODS AND SERVICES TO WHICH THIS WARRANTY RELATES.

IF YOU ARE UNABLE TO RETURN THE ITEM TO THE STORE OF PURCHASE, YOU CAN CONTACT LOVE N CARE ON FREECALL 1300732599. WE WILL THEN ORGANISE FOR EITHER SOMEBODY TO INSPECT THE ITEM OR ARRANGE FOR A COURIER TO PICK IT UP AND RETURN IT BACK TO YOU.

FOR MORE INFORMATION PLEASE CONTACT:



LOVE N CARE PTY LTD

EMAIL: info@lovencare.com.au

WEB: www.lovencare.com.au

PHONE: 1300 732 599

FAX: 02 9774 4633

VOYAGER

Spare Parts



1.



2.



3.




4.

- 1. 1 x Stroller Frame - Including, basket, seat and tether strap
- 2. 1 x Canopy
- 3. 1 x Front Wheels
- 4. 2 x Rear Wheels

VOYAGER

Instructions - Unlocking frame and seat



Unclip the latch from the frame.
(Located on the rear leg)



Open the frame by pulling the frame
in both directions until you hear a click
which indicates the frame is fully
opened and locked.



Push down on the stroller handle to make sure that
the frame is locked.

*PICTURES USED IN THIS MANUAL ARE FOR ILLUSTRATIVE PURPOSES ONLY. THE ACTUAL
STROLLER MAY VARY IN DISPLAY.

Instructions - Assemble/Use and remove the front wheel



To **assemble the front wheel**, place each front wheel and insert it into each of the wheel moulding.



Push the wheel on the wheel mouldings you should then hear a click. This should indicate that the wheels are locked in.



To **remove the front wheel**, press the button located on the bottom of the wheels moulding then pull down on wheel to remove it.



To **use the swivel wheel**, and lock the front wheels push the swivel lock down wards. To allow for the wheels to swivel push the swivel lock up wards. Always lock the swivel wheels when using the stroller on rough surfaces to minimise movement.

Instructions - Assemble and remove the rear wheels and use of brakes



To **assemble the rear wheels**, place each front wheel and insert it into each of the rear mouldings and push it in until you hear it click. Pull on the wheel to make sure it is placed correctly and locked in. Repeat for the other side.



To remove the rear wheels, pull the metal latch downward (located under the rear wheel moulding) to release the wheel. Pull the wheel from the frame.



To **lock the rear wheels**, press down on rear right red brake pedal to lock the brakes. Check that the brakes have been engaged by pushing the stroller forward.



To **release the brakes** push the rear brake pedal upwards.

⚠ WARNING ⚠

PUT ON ALL THE BRAKES WHENEVER YOU PARK THE STROLLER. ALWAYS APPLY THE BRAKES WHENEVER THE STROLLER IS STATIONARY.

Instructions - attaching the canopy



To **assemble the canopy**, insert the canopy mouldings into the frame mouldings.



The Canopy Moulding should click into the frame.



Attach the snap button from the canopy to the snaps located on the handle of the stroller.



Wrap the excess strap over the frame to the hook on canopy where the loop should be attached.



Attach the hook strip located on the inner edge of the canopy with the loop located on the sides of the stroller.



The Attached strips should look like this.



Attach the rectangle hooks from the bottom of the inner side of the canopy with the loops on the outer side of the stroller seat.



The Attached strips should look like this.



The attached canopy should look like this.

VOYAGER

Instructions - using the canopy



To adjust the canopy, you can open it by pulling it forward.



To close the canopy just push it backwards.



To open the canopy window, lift the canopy window backwards.
To place it back attach the loop onto the hook from the flap.



For extra air circulation, the rear flap from the canopy can be moved upwards. Remove the loops from the hooks (velcro straps). To re-attach just place the hooks over the loops.

Instructions - Adjusting the backrest and using the tether strap



To raise the backrest, hold the main adjuster moulding in one hand then grasp the plastic rings fixed to the adjuster straps with the other hand. Push up on the main adjuster moulding at the same time pull the Adjuster strap to the desired position.

To lower the backrest, support the backrest with one hand and with the other hand pull down on the backrest adjuster button and lower the backrest to the desired position



WARNING
USE THIS STRAP TO STOP THE STROLLER ROLLING AWAY

A wrist tether strap is attached on the handle of the stroller. Slide your hand through the tether strap loop whenever you use the stroller. Only remove your hand from the tether strap loop when the brakes have been applied to the strollers wheels.


Instructions - Using the Harness

⚠️ WARNING

USE THIS HARNESS AT ALL TIMES

⚠️ WARNING

WHEN NOT IN USE DISCONNECT SHOULDER STRAPS FROM THE WAIST STRAP AND/OR BUCKLE



Carefully place your child into the seat. Position its legs between the crotch strap. Place the shoulder strap (A) over the child's shoulders and place the waist strap (B) over its waist. Slide the shoulder strap buckle (A) along the rail on the top of the waist strap (B). Repeat for both sides.



With the shoulder strap (A) and waist strap (B) now connected, place them into the housing Buckle (C). You should hear them click into place. Repeat for the other side. To release the harness, squeeze the centre of the housing buckle. You can tighten or loosen the shoulder or waist straps by adjusting the sliders. Pull upwards to tighten or downwards to loosen.

VOYAGER

Instructions - Folding the stroller



To Fold the stroller, press the red safety lock button on the side of the stroller,



With the other hand lift the folding strap located on the seat unit.



Lock the frame together with the storage latch.

*PICTURES USED IN THIS MANUAL ARE FOR ILLUSTRATIVE PURPOSES ONLY. THE ACTUAL STROLLER MAY VARY IN DISPLAY.



Contact Us

Head Office:
Love N Care Pty Ltd.
297-299 Canterbury Rd, Revesby
NSW 2212 Australia
Contact No: 02 9774 4655
Fax: 02 9774 4633
Email: info@lovencare.com.au
Website: www.lovencare.com.au

Brisbane
7-9 Eileen Street
Underwood QLD 4119 Australia
Contact No: 07 3290 4217
Fax: 07 3209 5019

Western Australia
5 Modal Crescent
Canning Vale WA 6155 Australia
Contact No: 08 9455 4972
Fax: 08 9455 4728

let's be friends!

 <http://www.facebook.com/lovencare1>

 http://twitter.com/love_ncare



100 % AUSTRALIAN OWNED SINCE 1984

lovehncare[™]
lovencare.com.au